


Ride on Railways Hand Controller

For use with iDrive motor Controller.



Please Note

Pins 6,7 & 8 are only used if horn control is required. Curly flex only contains 6 wires so cannot be upgraded.

Plug & Socket Pin Num

